BALLARD DESIGNS.

HOW MUCH WALLPAPER DO I NEED?

If you have questions not addressed below, please call us at 800-535-8776. One of our representatives will be glad to assist you.

Measure the height of the room. Measure the distance around the room. Measure over any openings or cutouts, such as windows, doors, fireplaces, etc. Count the number of openings or cutouts which will not be covered. Use the chart below to determine the number of bolts or double rolls that you will need. You may deduct one double roll for every five openings not wallpapered.

This chart shows how many bolts or double rolls to purchase when the bolt is 20.5" wide and 33' long (11 yards).

	8	9	10	11	12
36	6	7	8	10	11
40	7	8	8	10	12
44	8	8	9	11	13
48	8	9	10	12	15
52	9	10	11	13	16
56	9	10	11	14	17
60	10	11	12	15	18
64	11	12	13	16	19
68	11	13	14	17	21
72	12	13	15	18	22
76	13	14	16	19	23
80	13	15	16	20	24
84	14	15	17	21	25
	40 44 52 56 60 64 68 72 76 80	8366407448488529569601064116811721276138013	8936674078448848895291056910601011641112681113721213761314	89103667840788407884488948891052910115691011601011126411121368111314721213157613141680131516	891011366781040788104488911488910125291011135691011146010111215641112131672121315187613141620

COVERAGE CHART CEILING HEIGHT IN FEET

NOTE: One double roll bolt covers approx. 50 square feet. This figure allows for pattern match waste trimming. NOTE: If the bolt is 27" wide, do not make deductions for openings (windows, doors, etc.)27" bolts are shorter and designs tend to have larger repeats.