




PRODUCT NAME: Hazel Desk Chair






ITEM NUMBER: UF090

ASSEMBLED DIMENSIONS : 31.25"-35"H x 26"W x 23.75"D



Prevent accidentally discarding small parts or hardware. Retain all carton contents until assembly and installation are complete.






⚠ Assemble in location for intended use.

Ltr.	Qty.	Hardware Included	
A	4		Allen Bolts
B	4		Lock Washers
C	4		Flat Washers
D	1		Allen Wrench
E	1		Wrench

REQUIRED TOOLS:
Allen Wrench (included),
Wrench (included)

-Two person assembly suggested.

Remove all parts, hardware and protective packaging from carton and carefully arrange on a clean, level, padded surface.

Ltr.	Qty.	Components	
F	1		
G	1		
H	1		
I	1		
J	4		
			
			




Cleaning and Care

Spot clean as needed.
Specific cleaning method varies by fabric type.




Customer Service: 800-367-2810
Online: www.ballarddesigns.com


STEP 1: Attach each Caster (J) to a Leg on Base Assembly (F). Insert threaded stud into hole in Leg. Use Wrench (E) to fully tighten and secure.



STEP 2: Orient Gas Lift (H) as illustrated with smaller end up. Center Metal Plate (G) over tip on Lift and press down. **IMPORTANT: REMOVE RED CAP FROM END OF GAS LIFT BEFORE ASSEMBLING!**



STEP 3: Invert Seat (F) onto a padded, clean surface. Invert Gas Lift/Metal Plate Assembly (G) and align holes with embedded T-nuts in Chair bottom. Attach using Allen Bolt (A), Lock Washer (B) and Lock Washer (C). Insert and hand-tighten all before fully tightening using Allen Wrench (D).



STEP 4: Carefully set Gas Lift (H) into center of Base (I). Push down to secure.

