

HOW MUCH WALLCOVERING DO I NEED?

Measure the height of the room. Measure the distance around the room. Measure over any openings or cutouts, such as windows, doors, fireplaces, etc. Count the number of openings or cutouts which will not be covered. Use the chart below to determine the number of bolts or double rolls that you will need. You may deduct one double roll for every five openings not wallpapered.

This chart shows how many bolts or double rolls to purchase when the bolt is 20.5" wide and 33' long (11 yards).

COVERAGE CHART

CEILING HEIGHT IN FEET

	8	9	10	11	12
36	6	7	8	10	11
40	7	8	8	10	12
44	8	8	9	11	13
48	8	9	10	12	15
52	9	10	11	13	16
56	9	10	11	14	17
60	10	11	12	15	18
64	11	12	13	16	19
68	11	13	14	17	21
72	12	13	15	18	22
76	13	14	16	19	23
80	13	15	16	20	24
84	14	15	17	21	25

DISTANCE AROUND ROOM IN FEET

NOTE: One double roll bolt covers approx. 50 square feet. This figure allows for pattern match waste trimming.

NOTE: If the bolt is 27" wide, do not make deductions for openings (windows, doors, etc.) 27" bolts are shorter and designs tend to have larger repeats.

OP178 06/06