


PRODUCT NAME: Gallery Easel

ITEM NUMBER: AS244

DIMENSIONS OF ITEM ASSEMBLED: 65"H x 13"W x 7 3/4"D

FIG 1



ASSEMBLY INSTRUCTIONS

STEP 1. Screw the main post (A) into the Easel Base (B). Tighten with the Metal Washer (C) and Nut (D) using the Wrench (E) as shown in Fig 1.

STEP 2. To adjust the height of each Bracket, loosen the large knob and move the Bracket up or down to the desired position. Fully tighten the knob in order for the Bracket to lock into place. If using a heavy piece of art, it is important to make sure the knobs are fully tightened before use.

NOTE: The maximum size art the Easel can hold is 50"H x 50"W x 1.75"D.

The maximum weight the Easel can hold is 25 lbs.