




PRODUCT NAME: Solar Outdoor Lantern

ITEM NUMBER: LO472

ASSEMBLED DIMENSIONS: 14" H x 10" Diameter or 10"H x 10" Diameter



IMPORTANT SAFETY INSTRUCTIONS:

- For your safety, please completely read Instruction Sheet before using lamp.
- Keep product out of reach of children.
- Do not remove screws or open lamp.
- Do not leave lamp outside in heavy rain. Protect from excessive moisture.
- Charge lamp in direct sunlight (Lamp must be OFF) or use DC-USB (included).
- Disconnect from charger when not in use.
- Do not drop or place heavy objects on lamp.
- Do not use lamp if cracked or broken.

WARNING:

- Built-in rechargeable battery is not replaceable.
- Do not remove or replace battery.
- Do not dispose lamp into trash. Refer to local regulations for proper disposal.
- Battery should be fully discharged before disposal.

ENVIRONMENTAL PROTECTION:




The symbol on the product dictates that Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

PARTS

Check to make sure you have the following:

INCLUDED:



1- Light (A)



1- DC - USB Cord (B)

NOTE: Remove all parts from the box along with any plastic protective packaging and carefully lay all the parts out on a clean, flat surface.

DO NOT discard any contents until after assembly and installation is complete to avoid accidentally discarding small parts or hardware.

Recommended Location for Use: Indoor/Outdoor Environment

Charging Time: Approximately 5 Hours via USB; 12 hours via solar.

Running Time: 2.5 hours@300 lumens; 3.5 hours@200 lumens; 7 hours@100 lumens



Cleaning and Care


Periodically dust with a soft, dry cloth.
Protect surfaces to prevent damage.
Do not use alcohol based cleaners or polishers.



Customer Service: 800-367-2810
Online: www.ballarddesigns.com

STEP 1: INSTALL CABLE AND CHARGE LAMP

- Connect USB Cable to a computer or any **5V OUTPUT** USB charging unit.
- Insert other end of Cable into DC port on Lamp (A)
- Charge for 5-6 hours (or until fully charged) prior to use.
- Indicator light is RED during CHARGING and GOES OUT when CHARGING IS COMPLETE.



STEP 2: POWERING LAMP

Turn On: Press and hold on/off button for 3 to 5 seconds.

Turn Off: Press and hold on/off button for 3 to 5 seconds.

Adjust Brightness: Low-Medium-High, quickly press and release.

FCC INSTRUCTION:

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Customer Service: 800-367-2810
Online: www.ballarddesigns.com