




PRODUCT NAME: Salerno Console

ITEM NUMBER: MS118



ASSEMBLED DIMENSIONS: 34"H x 68"W X 16"D



Prevent accidentally discarding small parts or hardware. Retain all carton contents until assembly and installation are complete.

⚠ Assemble in location for intended use.




i
Shelves and Hardware
Packet located
UNDER Console



REQUIRED TOOLS:
Phillips Screwdriver

-Two person assembly suggested.



Remove all parts, hardware and protective packaging from carton and carefully arrange on a clean, level, padded surface.


Ltr.	Qty.	Hardware Included	
A	8		Shelf Supports
B	4		Wood Plugs
C	2		Wall Anchoring (Anti-tip) Kits See Page 4



WARNING
Tip-Over Hazard
ANCHORING HARDWARE INCLUDED

Serious or fatal crushing injuries can occur from a furniture tip-over
Prevent tipping accidents. Anchor your furniture.

Ltr.	Qty.	Components	
D	2		Shelves (D)
E	1		Console (E)




Cleaning and Care


Periodically dust with a soft, dry cloth.
Prevent finish damage: do not use alcohol based
cleaners or polishers. Promptly remove spills.

⚠ Assemble in location for intended use.





SHELVES: Determine location for each Shelf (D) then insert Shelf Supports (A) into corresponding pre-drilled holes. Gently set each Shelf level upon Supports.



LEVELERS: Console is equipped with Rotary Levelers installed under each corner which are accessible from INSIDE Console. If necessary, Console may be adjusted by inserting a FLAT BLADE Screwdriver into opening and turning Leveler clockwise/counterclockwise. Cover Leveler access hole with Wood Plugs (B).



WALL ANCHORING HARDWARE (ANTI-TIP)

Ltr.	Qty.	Hardware Included	
A	2		Large Screw
B	2		Small Screw
C	4		Bracket
D	2		Retention Belt



Installation:

1. Place furniture against wall at desired location then locate and mark a Wall Stud behind unit.
2. Corresponding to Stud location, attach one Bracket (C) to back of unit using Small Screw (B).
3. To keep hardware out of view after installation, attach remaining Bracket (C) **INTO WALL STUD** with Large Screw (A) 2 inches below Bracket attached to back of unit.
4. Move unit into place, align Brackets then connect both using Retention Belt (D).
5. Confirm Belt is securely laced and locked.

