

# BALLARD DESIGNS.



PRODUCT NAME: Maisel Sideboard

ITEM NUMBER: SF111

ASSEMBLED DIMENSIONS: 36.5"H x 66"W x 18"D





# **REQUIRED TOOLS:**

Phillips Screwdriver


-Two person assembly suggested.

Ltr.	Qty.	Hardware/Components* Included	
А	4	Shelf Supports	
В	1	Shelves (B)	
С	2	Wall Anchoring (Anti-tip) Kit See page 2	

<sup>\*</sup>Hardware and Shelves separately packaged and ship on top of sideboard.

### **SHELVES:**

Insert Shelf Supports (A) into pre-drilled holes. Set each Shelf (B) level upon Supports.



**LEVELERS:** Sideboard is equipped with Rotary Levelers installed under each leg. If necessary, adjustments may be made by carefully lifting applicable corner and turning Levelers clockwise/counterclockwise.



#### **Cleaning and Care**

Periodically dust with a soft, dry cloth.

Prevent finish damage: do not use alcohol based cleaners or polishers. Promptly remove spills.

PRODUCTS ARE NOT INTENDED FOR COMMERCIAL USE. UPDATED: 3-20-2023

MADE IN VIETNAM

Page 1 of 2

# WALL ANCHORING HARDWARE (ANTI-TIP)

Ltr.	Qty.	Hardware Included	
A	2	<11111111111111111(%)	Large Screw
В	2	<uuti(%)< td=""><td>Small Screw</td></uuti(%)<>	Small Screw
С	4		Bracket
D	2		Retention Belt



## Installation:

- 1. Place furniture against wall at desired location then locate and mark a Wall Stud behind unit.
- 2. Corresponding to Stud location, attach one Bracket (C) to back of unit using Small Screw (B).
- 3. To keep hardware out of view after installation, attach remaining Bracket (C) **INTO WALL STUD** with Large Screw (A) 2 inches below Bracket attached to back of unit.
- 4. Move unit into place, align Brackets then connect both using Retention Belt (D).
- 5. Confirm Belt is securely laced and locked.

