


# BALLARD DESIGNS®

VENDOME DOUBLE PEDESTAL TABLE





TD263




90 1/4" \* 36" \* 30"



PRODUCTS ARE NOT INTENDED  
FOR COMMERCIAL USE.


No	Hardware	Qty
E	 Iron Plate	2
F	 Screw 5/16*1-3/4	8
G	 Flat Washer 5/16*19mm	8
H	 Lock Washer 5/16*14mm	8
I	 Allen Wrench M5	1
J	 Screw 1/4*3/4	8
K	 Flat Washer 1/4*16mm	8
L	 Lock Washer 1/4*11mm	8
M	 Allen Wrench M4	1

No	Parts	Qty
A	 Table Top	1PC
B	 Leaf	1PC
C	 Leg	2PCS
D	 Crossbar	1PC




Hardware pack here

Note: Two or more people are recommended to assemble this unit.




Step 1. Place the tabletop (A) upside down as shown (be sure to place on smooth clean surface to avoid scratching).




Step 2. Turn legs (C) so bottom faces up. Join legs (C) and crossbar (D) together through dowels.

Step 3. Attach iron plate (E) into the cut out groove on the bottom of the legs (C) and crossbar (D). Pilot holes are pre-drilled. Secure the iron plates using flat washers (K), lock washers (L) and screws (J) as shown. Turn the screws clockwise to tighten.



Step 4. Turn the legs upside down and place them on top of the upside down table top as shown, aligning the pre drilled holes on the legs with the predrilled holes in the table. Secure the legs to the table using screws (F), lock washers (H), and flat washers (G) with the allen wrench (I) as shown.



Step 5. When needed, the leaf (B) can be inserted or removed by aligning the leaf with the predrilled holes and dowels on the table top.

Step 6. If the unit needs leveling, adjust the levelers on the bottom of the legs, turning as needed for alignment.